Master Format #: 07 92 00

EUCO CLEAN-CUT JOINT FILLER STAIN PREVENTION FILM



PACKAGING

5 gallon (18.9 L) pail Code: 079A 05 1 gallon (3.8 L), 6 per case Code: 079A 95

APPROXIMATE COVERAGE

700 to 800 ft²/gal (17.2 to 19.6 m²/L), depending on the texture and porosity of the concrete, the type of joint filler used, and the width of film applied. One coat is normally adequate, but a second coat may be required if the concrete is extremely rough or porous. A test application is recommended to determine the required coverage rate.

CLEAN UP

Clean tools and equipment with water.

SHELF LIFE

2 years in original, unopened container

DESCRIPTION

EUCO CLEAN-CUT is a water-based blend of film-forming polymers that prevents staining of concrete due to overfill of epoxy or polyurea joint fillers. When applied to concrete adjacent to floor joints prior to filling, EUCO CLEAN-CUT dries to form a clear, glossy film that seals and protects the surface. After joint filling and shaving, EUCO CLEAN-CUT is easily removed with water. EUCO CLEAN-CUT also acts as a release film, making joint filler shaving operations faster and less labor-intensive.

PRODUCT CHARACTERISTICS

FEATURES/BENEFITS

- Prevents unsightly stains caused by joint material overfill
- Makes joint filler shaving easier
- Can be removed from concrete and tools with water
- Water-based, very low odor formula

PHYSICAL PROPERTIES

VOC Content: \leq 5 g/L Dry Time: 15 to 20 minutes @ 77 °F (25 °C), 40% RH

PRIMARY APPLICATIONS

- Concrete construction and control joints
- Especially suitable for colored concrete where appearance is critical

APPEARANCE

Clear liquid.

DIRECTIONS FOR USE

Concrete surfaces should be clean and dry. Ambient and concrete temperature must be between 40 to 90 °F (4 to 32 °C). EUCO CLEAN-CUT should be applied the same day as the joint filler installation. Apply EUCO CLEAN-CUT to concrete next to the unfilled joint using a small, short-napped paint roller, brush, or sprayer. **DO NOT ALLOW EUCO CLEAN-CUT TO FLOW INTO THE JOINT.** The interior of the joint must be protected from run-off or overspray. The width of film applied to the concrete surface adjacent to the joint will depend on the expected amount of joint material overfill. Allow EUCO CLEAN-CUT to dry completely before installation of joint filler. Dry time will depend on application rate as well as ambient temperature and humidity conditions. After joint filler shaving is complete, the remaining EUCO CLEAN-CUT can be removed with clean water. Allow the water to soften and dissolve the EUCO CLEAN-CUT film, then wash away. Some scrubbing with a brush or abrasive pad may be required. Use a household alkaline cleaner or detergent such as TSP (trisodium phosphate) to help remove stubborn spots or thick applications of EUCO CLEAN-CUT. **Removal of EUCO CLEAN-CUT must be done immediately after joints are filled and shaved. If the EUCO CLEAN CUT is allowed to remain on the concrete, removal may be extremely difficult.**

PRECAUTIONS/LIMITATIONS

- Do not use EUCO CLEAN-CUT at temperatures below 40 °F (4 °C).
- Do not allow EUCO CLEAN-CUT to freeze.
- The performance of EUCO CLEAN-CUT is dependent on the texture and porosity of the concrete and the type of joint filler used. A test section is strongly recommended to determine the thickness of EUCO CLEAN-CUT film required, and to estimate the overall effectiveness of the product given the site conditions.
- In all cases, consult the Safety Data Sheet before use.

WARRANTY: The Euclid Chemical Company ("Euclid") solely and expressly warrants that its products shall be free from defects in materials and workmanship for one (1) year from the date of purchase. Unless authorized in writing by an officer of Euclid, no other representations or statements made by Euclid or its representatives, in writing or orally, shall alter this warranty, EUCLID MAKES NO WARRANTIES, IMPLIED OR OTHERWISE, AS TO THE MERCHANTABILITY OR FITNESS FOR ORDINARY OR PARTICULAR PURPOSES OF ITS PRODUCTS AND EXCLUDES THE SAME. If any Euclid product fails to conform with this warranty, Euclid will replace the product at no cost to Buyer. Replacement of any product shall be the sole and exclusive remedy available and buyer shall have no claim for incidental or consequential damages. Any warranty claim must be made within one (1) year from the date of the claimed breach. Euclid does not authorize anyone on its behalf to make any written or oral statements which in any way alter Euclid's installation information or instructions in its product literature or on its packaging labels. Any installation of Euclid products which fails to conform with such installation information or instructions shall void this warranty. Product demonstrations, if any, are done for illustrative purposes only and do not constitute a warranty or warranty alteration of any kind. Buyer shall be solely responsible for determining the suitability of Euclid's products for the Buyer's intended purposes.